

PREPARING YOUR RADIO FOR USE

Attaching / removing the aerial



1. To attach, carefully align the aerial with the socket. Screw in the aerial clockwise (taking care not to cross the thread) until it is seated firmly. (A)
2. To remove, unscrew the aerial anti-clockwise. (B)

Attaching / removing the battery pack



1. To attach (C), locate the pegs on the bottom of the battery into the slots on the radio and pull the 2 latches downwards, carefully pushing the battery into the radio. Ensure the battery is fully latched.
2. To remove (D), pull down the 2 latches and carefully pull the battery away from radio.

SWITCHING ON, RECEPTION AND SWITCHING OFF

1. To switch on, rotate the on/off/volume control (1) on the top of the radio clockwise, you will hear a click from the control.
2. When the radio has passed its diagnostic tests, it will emit a fanfare tone.
3. The radio will enter standby mode. This is indicated by the LED Amber flashing once every 5 seconds, signalling that the radio is ready for use.
4. Adjust the volume control (1) to select the desired volume level.
5. Using the channel control (2) ensure that you have the correct channel selected.
6. When receiving a valid signal, the LED will illuminate steady green and audio will be emitted from the radio's speaker or audio accessory (if attached)
7. When finished using the radio, switch off by turning the on/off/volume control (1) counter clockwise until it clicks and the radio will be switched off.

TRANSMITTING

1. Perform steps 1 through to 5 of 'Switching On, Reception and Switching Off.'
2. Before transmitting, monitor the channel and make sure it is clear.
3. When receiving a signal, wait until the signal stops before transmitting. The transceiver cannot transmit and receive simultaneously.
4. Press the PTT (Push To Talk) button (3) to begin your transmission. To confirm transmission the LED illuminates red.
5. For best transmitted speech quality you must talk directly into the radio's microphone (5) at around 4cm between your mouth and the radio.
6. Please note: with your mouth further away, you will transmit poor quality speech.
7. When the transmission is finished, release the PTT button.

EU DECLARATION OF CONFORMITY

We, Entel UK Limited of:
320 Centennial Ave,
Centennial Park,
Elstree.
WD6 3TJ United Kingdom
Tel +44 208 236 0032
info@entel.co.uk

Declare under our sole responsibility that the product range specified below conforms to the following standards or other nominative documents;

HX400 V2 Series

EN 300 086-2 V1.3.1; EN 301 489-1:2008-7;
EN 301 489-5 V1.3.1:2002-08;
EN 60950-1:2006

In accordance with directive 1999/5/EC

Name: Mike Jamieson
Position: Quality Manager
Date: 17 January 2016
Signed:

www.entel.co.uk

HX Series

Quick Start User Guide



Designed in the United Kingdom

HX Series

INTRODUCTION

The HX series is a professional range of compact commercial grade portables, designed and manufactured to meet IP55 specification for superior protection against dust and liquid ingress.

This quick guide provides basic guidance for operating your radio. A full version of this user guide is available to download from our website, www.entel.co.uk.

To meet your exact requirements the radio may have been customised by your Entel dealer. These features will be explained in a separate guide issued by the dealer.

PACKING LIST

HX4xx	Transceiver
CNB450E	Rechargeable Li-Ion battery
CBH450	Spring loaded belt clip
CATxxx	High efficiency antenna
CSAHX	Rapid charger (HXxx2 & HXxx3 Entry models only)

OPTIONAL ACCESSORIES

Attaching and removing accessories

To attach an accessory, remove the accessory cover by unscrewing the locking screw anti-clockwise (please store the removed cover in a safe place).

Plug the accessory into the socket, then carefully tighten the locking screw clockwise until finger tight (Do not use any implement or overtighten).

To remove an accessory, unscrew the locking screw of the accessory by hand in an anti-clockwise direction. Ensure you re-fit the accessory socket cover so as to protect the socket.



BATTERY INFORMATION

Battery charging

1. Connect the AC adapter to the charger pod and plug in.
2. Turn the transceiver off.
3. Insert the battery pack into the charger pod, either with or without the transceiver attached. The charger LED status light changes to red and charging begins.
4. When charging is complete the charger status LED changes from red to green (a fully discharged battery pack will take approximately 3 hours to recharge).

A flashing red LED on the charger indicates there is a problem with the battery. Remove the battery from the charger and consult your Entel Dealer.

CAUTION

BATTERY PACK PRECAUTIONS

- Do not recharge the battery pack if it is already fully charged. Doing so may cause the life of the battery pack to shorten or the battery pack may be damaged.
- After charging is complete, remove the battery from the charger. If the power to the charger is turned off and on again, charging will restart and the battery will become overcharged.
- Please ensure that the radio is turned off before placing it in the charger and never switch a radio on whilst in the charger.
- Only use Entel branded battery pack and chargers.
- Do not short the battery terminals or dispose of the battery in a fire.
- Do not charge the transceiver and/or battery pack if they are wet.

DANGER

DO NOT DISASSEMBLE OR MODIFY THE BATTERY IN ANY WAY!

Your Entel battery pack incorporates safety circuitry to avoid danger. If the safety circuitry is damaged or bypassed, or the battery cells are damaged directly, they may generate extreme heat, smoke, rupture and emit flames.

NON DISPLAY



LCD DISPLAY



8 KEY LCD



20 KEY LCD



1. On/Off/Volume control. Rotate clockwise to turn on and increase volume. Rotate anti-clockwise to reduce volume & turn off.
2. Channel control
3. Push To Talk (PTT) button. Press to speak and release to listen
4. Dealer programmable buttons (ask your dealer for more information)
5. Microphone
6. Keypad (8 keys)

7. Full keypad (20 Keys)
 8. Dealer programmable button and LED indicator
- Red steady** - Transmitting
- Red flashing slowly** - Battery needs recharging
- Green steady** - Receiving
- Amber steady** - Invalid signal being received
- Amber flashing rapidly** - Scanning
- Amber pulsing** - In standby mode